

2 EASY STEPS

TO CHOOSE THE RIGHT AIR CONDITIONER



FUJITSU

STEP 1

WHAT IS YOUR ROOM SIZE?

STEP 2

IS YOUR CEILING + INSULATED?

DO YOUR WINDOWS FACE WEST?

- CEILING **IS** INSULATED + WINDOWS **DON'T** FACE WEST
- CEILING **IS** INSULATED + WINDOWS **DO** FACE WEST
- CEILING **NOT** INSULATED + WINDOWS **DON'T** FACE WEST
- CEILING **NOT** INSULATED + WINDOWS **DO** FACE WEST

10-15m²

ASTG09KMTC
● ● ● ●
 ASTG12KMTC
●

16-20m²

ASTG09KMTC
●
 ASTG12KMTC
● ● ●

21-25m²

ASTG12KMTC
● ●
 ASTG18KMTC
● ●

26-30m²

ASTG18KMTC
● ● ● ●

31-35m²

ASTG18KMTC
● ● ●
 ASTG22KMTC
●

36-40m²

ASTG18KMTC ●
 ASTG22KMTC ●
 ASTG24KMTC ●

41-45m²

ASTG22KMTC ●
 ASTG24KMTC ● ●
 ASTG30KMTC ●

46-50m²

ASTG24KMTC ● ●
 ASTG30KMTC ●
 ASTG34KMTC ●

51-55m²

ASTG30KMTC
● ●
 ASTG34KMTC
● ●

56-60m²

ASTG30KMTC
●
 ASTG34KMTC
● ●

61-65m²

ASTG34KMTC
● ●

66-70m²

ASTG34KMTC
●